



HDCP2.2

4K2K



## EL-41HP-4K22

4-Way Advanced HDMI Switcher (4K, HDCP2.2, HDMI2.0,  
IR, RS-232, IP, Web GUI)

**OPERATION MANUAL**



## **DISCLAIMERS**

The information in this manual has been carefully checked and is believed to be accurate. CYP (UK) Ltd assumes no responsibility for any infringements of patents or other rights of third parties which may result from its use.

CYP (UK) Ltd assumes no responsibility for any inaccuracies that may be contained in this document. CYP (UK) Ltd also makes no commitment to update or to keep current the information contained in this document.

CYP (UK) Ltd reserves the right to make improvements to this document and/or product at any time and without notice.

## **COPYRIGHT NOTICE**

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means—electronic, mechanical, magnetic, optical, chemical, manual, or otherwise—without express written permission and consent from CYP (UK) Ltd.

© Copyright 2011 by CYP (UK) Ltd.

All Rights Reserved.

Version 1.1 August 2011

## **TRADEMARK ACKNOWLEDGMENTS**

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.

## SAFETY PRECAUTIONS

Please read all instructions before attempting to unpack, install or operate this equipment and before connecting the power supply.

Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through any openings or empty slots in the unit, as you may damage parts inside the unit.
- Do not attach the power supply cabling to building surfaces.
- Use only the supplied power supply unit (PSU). Do not use the PSU if it is damaged.
- Do not allow anything to rest on the power cabling or allow any weight to be placed upon it or any person walk on it.
- To protect the unit from overheating, do not block any vents or openings in the unit housing that provide ventilation and allow for sufficient space for air to circulate around the unit.

## REVISION HISTORY

| VERSION NO. | DATE       | SUMMARY OF CHANGE |
|-------------|------------|-------------------|
| v1.00       | 21/11/2017 | First release     |
|             |            |                   |

# CONTENTS

|  |           |
|--|-----------|
| <b>1. Introduction .....</b>                     | <b>6</b>  |
| <b>2. Applications .....</b>                     | <b>6</b>  |
| <b>3. Package Contents .....</b>                 | <b>6</b>  |
| <b>4. System Requirements .....</b>              | <b>6</b>  |
| <b>5. Features.....</b>                          | <b>7</b>  |
| <b>6. Operation Controls and Functions .....</b> | <b>8</b>  |
| 6.1 Front Panel .....                            | 8         |
| 6.2 Rear Panel.....                              | 9         |
| 6.3 Remote Control .....                         | 9         |
| 6.4 IR Cable Pin Assignments .....               | 10        |
| 6.5 RS-232 Protocol .....                        | 10        |
| 6.6 RS-232 and Telnet Commands.....              | 11        |
| 6.7 Telnet Control.....                          | 14        |
| 6.8 WebGUI Control .....                         | 15        |
| <b>7. Connection Diagram .....</b>               | <b>20</b> |
| <b>8. Specifications.....</b>                    | <b>21</b> |
| 8.1 Technical Specifications .....               | 21        |
| 8.2 Video Specifications.....                    | 22        |
| <b>9. Acronyms.....</b>                          | <b>23</b> |

## 1. INTRODUCTION

This 4-Way HDMI Switcher is designed to enable the user to switch between any of the four connected HDMI sources to send video and audio to a single HDMI display. This switcher fully supports 4K resolutions and is HDMI2.0 and HDCP 2.2 compliant, ensuring maximum compatibility with the latest 4K UHD sources and displays. The EL-41HP-4K22 supports all the latest features of the HDMI 2.0 specification such as 4K UHD resolutions (4K2K@60Hz - YUV4:4:4),HDR (High Dynamic Range), 'Deep Colour', and High Definition audio.

In addition, this switcher also features an Auto-Switching function which detects the last active input and switches to this input automatically for display. The management of source/sink configurations can be easily controlled via the on-board WebGUI LAN control, IR remote control and RS-232.

## 2. APPLICATIONS

- /// Entertainment Rooms & Home Theaters
- /// Showrooms & Demo Rooms
- /// Lecture Room & Hall Presentations
- /// Public Commercial Displays

## 3. PACKAGE CONTENTS

- /// 1×4 by 1 HDMI Switcher
- /// 1×Remote Control (CR-72)
- /// 1×IR Extender Cable
- /// 1×5V/2.6A DC Power Adaptor
- /// 1×Operation Manual

## 4. SYSTEM REQUIREMENTS


- /// HDMI source equipment such as media players, video game consoles or set-top boxes.
- /// HDMI receiving equipment such as HDTVs, monitors or audio amplifiers.

## 5. FEATURES

- /// HDMI 2.0 with 18Gbps 4K UHD support, single-link DVI 1.0 compliant
- /// HDCP 2.2 and 1.4 compliant
- /// 4 HDMI inputs and 1 HDMI output
- /// Supports HDTV resolutions up to 4K UHD (3840×2160@50/60Hz & 4096×2160@50/60Hz)
- /// Supports data rates up to 18Gbps and Deep Colour (16-bit) up to 1080p
- /// Supports pass-through of LPCM 7.1, Bitstream and HD Bitstream audio formats
- /// Remotely controllable via Ethernet (WebGUI & Telnet), RS-232 and IR remote


## 6. OPERATION CONTROLS AND FUNCTIONS

### 6.1 Front Panel



- ② **IR WINDOW:** Accepts IR signals from the included IR remote for control of this unit only.
- ② **POWER:** Press this button to power on the unit or place it into stand-by mode.  
*Note: Ethernet and RS-232 remain active while the unit is in stand-by mode.*
- ② **POWER LED:** The LED will illuminate RED to indicate the unit is receiving power but is in stand-by mode. It will illuminate GREEN to indicate that the unit has been turned on.
- ② **SYNC LED:** This LED will illuminate GREEN when a stable connection with an output device is detected.
- ② **INPUT:** Press this button to sequentially switch through the 4 available inputs.
- ② **INPUT LED 1~4:** These LEDs will illuminate GREEN to indicate which of the 4 sources are currently selected.


## 6.2 Rear Panel




- ② **HDMI IN 1~4:** Connect to HDMI source equipment such as a media player, game console or set-top box. DVI source equipment may be connected by using an HDMI to DVI adapter.
- ② **HDMI OUT:** Connect to HDMI TVs, monitors or amplifiers for digital video and audio output. DVI display equipment may be connected by using an HDMI to DVI adapter.
- ② **SERVICE:** This slot (USB 2.0) is reserved for firmware update use only.
- ② **CONTROL:** Connect directly, or through a network switch, to your PC/ laptop to control the unit via Telnet/WebGUI.
- ② **RS-232:** Connect directly to your PC/laptop to send RS-232 commands to control the unit.
- ② **IR IN:** Connect to the provided IR Extender to extend the IR control range of the unit. Ensure that the remote being used is within direct line-of-sight of the IR Extender.
- ② **DC 5V:** Plug the 5V DC power adapter into the unit and connect it to an AC wall outlet for power.

## 6.3 Remote Control

- ② **POWER:** Press this button to power on the unit or place it into stand-by mode.
- ② **INPUT 1~4:** Press 1 through 4 to select the input source.



## 6.4 IR Cable Pin Assignments



## 6.5 RS-232 Protocol

| UNIT |            |   | REMOTE SYSTEM |            |
|------|------------|---|---------------|------------|
| Pin  | Definition |   | Pin           | Definition |
| 1    | NC         |   | 1             | NC         |
| 2    | TxD        |   | 2             | RxD        |
| 3    | RxD        |   | 3             | TxD        |
| 4    | NC         | ▶ | 4             | NC         |
| 5    | GND        | ◀ | 5             | GND        |
| 6    | NC         |   | 6             | NC         |
| 7    | NC         |   | 7             | NC         |
| 8    | NC         |   | 8             | NC         |
| 9    | NC         |   | 9             | NC         |

Baud Rates: 115200bps

Data Bits: 8

Parity Bits: None

Stop Bit: 1

Flow Control: None

## 6.6 RS-232 and Telnet Commands

| COMMAND             | DESCRIPTION AND PARAMETERS   |
|---------------------|--|
| <b>HELP</b>         | Displays all available commands.   |
| <b>?</b>            | Displays all available commands.   |
| <b>P0</b>           | Turn unit's power off. (Stand-by mode)   |
| <b>P1</b>           | Turn unit's power on.  |
| <b>INNAME N1 N2</b> | Set the name of input N1 to N2.<br>N1 = 1~4 [Input number]<br>N2 = {name} [8 characters max]                             |
| <b>INNAME N1</b>    | Show the input name of N1.<br>N1 = 1~4 [Input number]  |
| <b>INNAME</b>       | Show the names of all inputs.  |
| <b>OUTNAME N1</b>   | Set the output name to N1.<br>N1 = {name} [8 characters max]   |
| <b>OUTNAME</b>      | Show the current output name.  |
| <b>OUT N1</b>       | Set the input to be routed to the output.<br>N1 = 1~4 [Input number]   |
| <b>OUT</b>          | Show the current input routing.  |
| <b>SOURCEDET</b>    | Show all source information.   |
| <b>SINKINFO</b>     | Show all sink information.   |
| <b>HDCPIN N1 N2</b> | Set the HDCP mode for input N1.<br>N1 = 1~4 [Input number]<br>Available values for N2:<br>0 [Standard]<br>1 [Apple Mode] |
| <b>HDCPIN N1</b>    | Show the HDCP settings for input N1.<br>N1 = 1~4 [Input number]  |
| <b>HDCPIN</b>       | Show all current HDCP input settings.  |

| COMMAND             | DESCRIPTION AND PARAMETERS  |
|---------------------|---|
| <b>EDIDMODE N1</b>  | Set the EDID mode.<br><br>Available values for N1:<br>0 [Appoint]<br>1 [All]  |
| <b>EDIDMODE</b>     | Show the current EDID mode setting.   |
| <b>EDIDALL N1</b>   | Set the EDID to use in "All" mode.<br><br>Available values for N1:<br>0 [SINK]<br>1 [720P]<br>2 [1080P]<br>3 [4K_3G]<br>4 [4K_Y420]<br>5 [4K_6G]  |
| <b>EDIDALL</b>      | Show the current EDID selection for "All" mode.   |
| <b>EDIDIN N1 N2</b> | Set the EDID to use on input N1 in "Appoint" mode.<br><br>N1 = 1~4 [Input number]<br><br>Available values for N2:<br>0 [SINK]<br>1 [720P]<br>2 [1080P]<br>3 [4K_3G]<br>4 [4K_Y420]<br>5 [4K_6G] |
| <b>EDIDIN N1</b>    | Show the current EDID selection for input N1 in "Appoint" mode.   |
| <b>EDIDIN</b>       | Show the current EDID selections for all inputs in "Appoint" mode.  |


| COMMAND               | DESCRIPTION AND PARAMETERS  |
|-----------------------|---|
| <b>AUTO_SWITCH N1</b> | Enable or disable auto switching mode.<br>Available values for N1:<br>0 [Disabled]<br>1 [Enabled] |
| <b>AUTO_SWITCH</b>    | Show current auto switching mode status.  |
| <b>FADEFAULT</b>      | Reset the unit to the factory defaults.   |
| <b>REBOOT</b>         | Reboot the unit.  |
| <b>VER</b>            | Show the unit's current firmware version.   |
| <b>IPCONFIG</b>       | Show the current IP configuration.  |
| <b>SIPADDR N1</b>     | Set the static IP Address.<br>N1 = X.X.X.X [X = 0~255]  |
| <b>SNETMASK N1</b>    | Set the Ethernet netmask.<br>N1 = X.X.X.X [X = 0~255]   |
| <b>SGATEWAY N1</b>    | Set the Ethernet gateway.<br>N1 = X.X.X.X [X = 0~255]   |
| <b>HTTPPORT N1</b>    | Set the HTTP port.<br>N1 = 0~65535  |
| <b>TELNETPORT N1</b>  | Set the Telnet port.<br>N1 = 0~65535  |
| <b>IPMODE N1</b>      | Set the current IP address mode.<br>Available values for N1:<br>0 [Static IP]<br>1 [DHCP]         |
| <b>READMAC</b>        | Show the unit's MAC address.  |
| <b>UPDATE</b>         | Update firmware.  |

*Note: Commands will not be executed unless followed by a carriage return. Commands are not case-sensitive.*

## 6.7 Telnet Control

Before attempting to use Telnet control, please ensure that both the unit and the PC/Laptop are connected to the same active networks.

To access Telnet in Windows 7, click on the “Start” menu and type “cmd” in the search field, then press “Enter”. Under Windows XP go to the “Start” menu, click on “Run”, type “cmd” then press “Enter”. Under Mac OS X, go to “Go→Applications→Utilities→Terminal”. See below for reference.



Once in the CLI (Command Line Interface) type “Telnet” followed by the IP address of the unit and “23”, then hit “Enter”.

```
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

C:\Users\Administrator>telnet 192.168.1.50 23
```

This will connect us to the unit we wish to control. Type “help” to list the available commands.

Notes:

*Commands will not be executed unless followed by a carriage return.  
Commands are not case-sensitive.*

*If the IP address is changed then the IP address required for Telnet access will also change accordingly.*

## 6.8 WebGUI Control

### 6.8.1 Device Discovery APP

Please obtain the “Device Discovery” software from your authorised dealer and save it in a directory where you can easily find it.

Connect the unit and your PC/Laptop to the same active network and execute the “Device Discovery” software. Click on “Find Devices on Network” and a list of devices connected to the local network will show up indicating their current IP address. (The unit’s default IP address is 192.168.1.50)

| Product Name | Description | IP Address | MAC Address |
|--------------|-------------|------------|-------------|
|              |             |            |             |

By clicking on one of the listed devices you will be presented with the network details of that particular device.

Product ID  
 Product Name  
 MAC Address 00:00:00:00:00:00  
 IP Address   
 Subnet Mask   
 Gateway IP   
 DNS   
 IP Mode   
 Web GUI Port   
 Telnet Port   
 S / N  
 Firmware Version  
 Hardware Version  
 Description  
 Web GUI [Web GUI](#)

**IP Mode:** If you choose, you can alter the static IP network settings for the device, or switch the unit into DHCP mode to automatically obtain proper network settings from a local DHCP server. To switch to DHCP mode, please select DHCP from the IP mode drop-down, then click “Save” followed by “Reboot”.

**WebGUI:** Once you are satisfied with the network settings, you may use them to connect via Telnet or WebGUI. The network information window provides a convenient link to launch the WebGUI directly.

## 6.8.2 WebGUI Control Page

All functions, including power, input selection, EDID management, HDCP management, port naming, Ethernet settings, and reset/firmware functions, are presented on a single web page to allow for simple and intuitive operation. The individual functions will be explained in the following sections.

The screenshot displays the WebGUI Control Page with the following sections:

- POWER:** A dropdown menu set to "ON".
- ROUTING:** A dropdown menu set to "INPUT1".
- SOURCE DETECT:** Four input status indicators: INPUT1: ON, INPUT2: OFF, INPUT3: OFF, INPUT4: OFF.
- STATUS:** HDMI OUT: INPUT1, VERSION: V2.4, with "RESET" and "REBOOT" buttons.
- EDID:** Mode: ALL, EDID ALL: 8/2D/PCM/1080p.
- HDCP CONTROL:** Four input dropdown menus, all set to "Standard".
- FIRMWARE UPDATE:** "BROWSE" and "UPDATE" buttons.
- NAMING:** Input fields for INPUT1, INPUT2, INPUT3, INPUT4, and OUTPUT, with a "SAVE" button.
- NETWORK SETTING:** MAC, IP Mode (STATIC), IP Address (192.168.1.50), Net Mask (255.255.255.0), Gateway (192.168.1.254), HTTP Port (80), and Telnet Port (23), with an "APPLY" button.
- HDMI OUT INFO:** Type: HDMI, Manuf. Name: STD, Native Resolution: 1920x1080p, Color Depth: 8 10 12-Bits, 3D: YES, 4K2K: NO, Audio Format: PCM/BitStream.


### 1. Power

The unit can be powered on or off (stand-by mode) from this tab.



### 2. Routing

This tab allows for the selection of the input source. Four HDMI inputs are available for selection.




### 3. EDID

This tab controls EDID management for the unit. All inputs can share the same assigned EDID, or each input can have a discrete EDID assigned to it.

**ALL:** Selecting the “ALL” mode will send the selected EDID to all inputs.

**APPOINT:** Selecting the “APPOINT” mode allows for each input to have a different EDID assigned to it.



The available EDID options are:

**SINK:** EDID is passed from the currently connected display


**8/2D/PCM/720p:** 720p@60Hz, 8-bit & LPCM 2.0

**8/2D/PCM/1080p:** 1080p@60Hz, 8-bit & LPCM 2.0

**8/2D/PCM2/4K 3G:** 4K@30Hz, 8-bit & LPCM 2.0

**8/2D/PCM2/4K Y420:** 4K@60Hz (4:2:0), 8-bit & LPCM 2.0

**8/2D/PCM/4K 6G:** 4K@60Hz (4:4:4), 8-bit & LPCM 2.0



### 4. HDCP Control

This tab allows for the HDCP mode to be switched between “Standard” and “Apple” mode. “Apple” mode allows for the display of non-HDCP required content from Apple devices on non-HDCP displays. This setting can be assigned individually to each input.



## 5. Naming

This tab allows for the renaming of the four HDMI input ports and the HDMI output port. Please click the “SAVE” button to store the changes.

The NAMING window contains the following fields:

- INPUT1: INPUT1
- INPUT2: INPUT2
- INPUT3: INPUT3
- INPUT4: INPUT4
- OUTPUT: OUTPUT

A SAVE button is located at the bottom center.

## 6. Network Setting

This tab provides control over the unit’s network settings. The IP mode can be set to “DHCP” for automatic IP configuration, if your local network supports it, or it can be placed in “Static” mode and the IP address, netmask and gateway can be defined manually. The HTTP and Telnet ports can also be changed from their defaults here.

The NETWORK SETTINGS window contains the following fields:

- MAC:
- IP Mode: STATIC
- IP Address: STATIC
- Net Mask: DHCP
- Gateway: 192.168.1.254
- HTTP Port: 80
- Telnet Port: 23

An APPLY button is located at the bottom center.

## 7. Source Detect

When a live input source is connected one of the 4 HDMI inputs the corresponding input port in this tab will display “ON”. If no source is detected on that input, it will display “OFF”.

The SOURCE DETECT window contains the following fields:

- INPUT1: ON
- INPUT2: OFF
- INPUT3: OFF
- INPUT4: OFF

## 8. Status

This tab displays the currently selected HDMI input source and the unit's firmware version as well as allowing for resetting or rebooting the unit.

**RESET:** To perform a factory reset on the unit, please click the "RESET" button.

**REBOOT:** To reboot the unit, please click "REBOOT" button.



## 9. Firmware Update

This tab provides a way to update the firmware of the unit.


**BROWSE:** Click the "BROWSE" button to select the firmware update \*.bin file which is located on your local PC.

**UPDATE:** Click the "UPDATE" button to begin the firmware update process.




## 10. HDMI Out Info

The HDMI output display's detected information is listed here, including type, manufacturer name, native resolution, colour depth, 3D support, 4K support and audio format support.



## 7. CONNECTION DIAGRAM



## 8. SPECIFICATIONS

### 8.1 Technical Specifications

|                              |  |
|------------------------------|--|
| <b>Video Bandwidth</b>       | 600MHz/18Gbps  |
| <b>Input Ports</b>           | 4×HDMI   |
| <b>Output Ports</b>          | 1×HDMI   |
| <b>Control Interfaces</b>    | 1×IR Extender (3.5mm)<br>1×RS-232 (9-pin D-sub)<br>1×IP Control (RJ45)                 |
| <b>Supported Resolutions</b> | 480i@60Hz - 4K@60Hz (4:4:4, 8-bit)<br>VGA@60Hz - WUXGA@60Hz (RB)                       |
| <b>HDMI Cable Length</b>     | 10m (1080p@60Hz, 12-bit)<br>5m (4K@60Hz, 4:4:4, 8-bit)                                 |
| <b>IR Frequency</b>          | 30 - 50kHz (30 - 60kHz under ideal conditions)   |
| <b>Baud Rate</b>             | 115200bps  |
| <b>Power Supply</b>          | 5V/2.6A DC (US/EU standards, CE/FCC/UL certified)                                      |
| <b>ESD Protection</b>        | Human Body Model:<br>±12kV (Air Discharge)<br>±8kV (Contact Discharge)                 |
| <b>Dimensions</b>            | 240mm×43mm×104mm (W×H×D)<br>[Case Only]<br>240mm×48mm×112mm (W×H×D)<br>[All Inclusive] |
| <b>Weight</b>                | 850g   |
| <b>Chassis Material</b>      | Metal  |
| <b>Silkscreen Colour</b>     | Black  |
| <b>Operating Temperature</b> | 0°C - 40°C/32°F - 104°F  |
| <b>Storage Temperature</b>   | -20°C - 60°C/-4°F - 140°F  |
| <b>Relative Humidity</b>     | 20 - 90% RH (Non-condensing)   |
| <b>Power Consumption</b>     | 5.83W  |

## 8.2 Video Specifications

| Supported PC Resolutions (Hz) | Input | Output |
|-------------------------------|-------|--------|
| <b>640×480@60/72/75</b>       | ✓     | ✓      |
| <b>800×600@60/72/75</b>       | ✓     | ✓      |
| <b>1024×768@60/70/75</b>      | ✓     | ✓      |
| <b>1280×768@60</b>            | ✓     | ✓      |
| <b>1280×1024@60</b>           | ✓     | ✓      |
| <b>1360×768@60</b>            | ✓     | ✓      |
| <b>1600×1200@60</b>           | ✓     | ✓      |
| <b>1920×1200@60 (RB)</b>      | ✓     | ✓      |

| Supported TV Resolutions (Hz)    | Input | Output |
|----------------------------------|-------|--------|
| <b>480i@60</b>                   | ✓     | ✓      |
| <b>576i@50</b>                   | ✓     | ✓      |
| <b>480p@60</b>                   | ✓     | ✓      |
| <b>576p@50</b>                   | ✓     | ✓      |
| <b>720p@50/60</b>                | ✓     | ✓      |
| <b>1080i@50/60</b>               | ✓     | ✓      |
| <b>1080p@24/25/30/50/60</b>      | ✓     | ✓      |
| <b>3840×2160p@50/60 (4:2:0)</b>  | ✓     | ✓      |
| <b>4096×2160p@50/60 (4:2:0)</b>  | ✓     | ✓      |
| <b>3840×2160p@24/25/30/50/60</b> | ✓     | ✓      |
| <b>4096×2160p@24/50/60</b>       | ✓     | ✓      |

## 9. ACRONYMS

| ACRONYM      | COMPLETE TERM  |
|--------------|--|
| <b>CLI</b>   | Command Line Interface                                 |
| <b>DVI</b>   | Digital Visual Interface                               |
| <b>EDID</b>  | Extended Display Identification Data                   |
| <b>GUI</b>   | Graphical User Interface                               |
| <b>HD</b>    | High-Definition  |
| <b>HDCP</b>  | High-bandwidth Digital Content Protection              |
| <b>HDMI</b>  | High-Definition Multimedia Interface                   |
| <b>HDR</b>   | High Dynamic Range                                     |
| <b>HTTP</b>  | HyperText Transfer Protocol                            |
| <b>IP</b>    | Internet Protocol                                      |
| <b>IR</b>    | Infrared   |
| <b>LAN</b>   | Local Area Network                                     |
| <b>LPCM</b>  | Linear Pulse-Code Modulation                           |
| <b>PC</b>    | Personal Computer                                      |
| <b>UHD</b>   | Ultra-High-Definition                                  |
| <b>USB</b>   | Universal Serial Bus                                   |
| <b>VGA</b>   | Video Graphics Array (640×480@60Hz)                    |
| <b>WUXGA</b> | Wide Ultra Extended Graphics Array<br>(1920×1200@60Hz) |



---

CYP (UK) Ltd., Unit 7, Shepperton Business Park, Govett Avenue, Shepperton,  
Middlesex, TW17 8BA

Tel: +44 (0) 20 3137 9180 | Fax: +44 (0) 20 3137 6279

Email: [sales@cypeurope.com](mailto:sales@cypeurope.com)

[www.cypeurope.com](http://www.cypeurope.com)

v1.00